

<u>MODEL(S)</u> <u>OR SERIES</u>	<u>DESCRIPTION</u>	<u>DRAWING</u> <u>NUMBER</u>	<u>DRAWING</u> <u>DATE</u>
HORIZONTAL FAN COIL UNITS			
38F, 38FW, 38FE	Underfloor • Fan Booster • Unit Sizes 1, 3 and 5	38F-1	3-9-09
38FW, 38FE	Underfloor * Fan Booster • Heat Accessories • Unit Sizes 1, 3 and 5	38F-1	3-9-09
38F, 38FW, 38FE	Underfloor • Fan Booster • Supply and Return Dampers • Unit Sizes 1, 3 and 5 • Left Hand Layout	38F-1DLH	3-9-09
38FW, 38FE	Underfloor • Fan Booster • Supply and Return Dampers • Heat Accessories • Unit Sizes 1, 3 and 5 • Left Hand Layout	38F-1DLH	3-9-09
38F, 38FW, 38FE	Underfloor • Fan Booster • Supply and Return Dampers • Unit Sizes 1, 3 and 5 • Right Hand Layout	38F-1DRH	3-9-09
38FW, 38FE	Underfloor • Fan Booster • Supply and Return Dampers • Heat Accessories • Unit Sizes 1, 3 and 5 • Right Hand Layout	38F-1DRH	3-9-09
38F, 38FW, 38FE	Underfloor • Fan Booster • Unit Size 3S	38F-2	8-20-08
38FW, 38FE	Underfloor • Fan Booster • Heat Accessories • Unit Size 3S	38F-2	8-20-08
38F, 38FW, 38FE	Underfloor • Fan Booster • Unit Size 6	38F-6	8-20-08
38FW	Underfloor • Fan Booster • Hot Water Heat • Unit Size 6	38F-6	8-20-08
38FE	Underfloor • Fan Booster • Electric Heat • Unit Size 6	38F-6	8-20-08
38F, 38FW, 38FE	Underfloor • Fan Booster • Cooling and Heating Dampers • Unit Size 6	38F-6DRH	8-20-08
38FW	Underfloor • Fan Booster • Cooling and Heating Dampers • Hot Water Heat • Unit Size 6	38F-6DRH	8-20-08
38FE	Underfloor • Fan Booster • Cooling and Heating Dampers • Electric Heat • Unit Size 6	38F-6DRH	8-20-08
38F, 38FW, 38FE	Underfloor • Fan Booster • Cooling and Heating Dampers • Unit Size 33 • Left Hand Layout	38F-33DLH	8-20-08
38FW	Underfloor • Fan Booster • Cooling and Heating Dampers • Hot Water Heat • Unit Size 33 • Left Hand Layout	38F-33DLH	8-20-08
38FE	Underfloor • Fan Booster • Cooling and Heating Dampers • Electric Heat • Unit Size 33 • Left Hand Layout	38F-33DLH	8-20-08
38F, 38FW, 38FE	Underfloor • Fan Booster • Cooling and Heating Dampers • Unit Size 33 • Right Hand Layout	38F-33DRH	8-20-08
38FW	Underfloor • Fan Booster • Cooling and Heating Dampers • Hot Water Heat • Unit Size 33 • Right Hand Layout	38F-33DRH	8-20-08
38FE	Underfloor • Fan Booster • Cooling and Heating Dampers • Electric Heat • Unit Size 33 • Right Hand Layout	38F-33DRH	8-20-08



UNDERFLOOR PRODUCTS SUBMITTAL INDEX

BDate: May 18, 2009
Supersedes: Dec. 1, 2008

<u>MODEL(S) OR SERIES</u>	<u>DESCRIPTION</u>	<u>DRAWING NUMBER</u>	<u>DRAWING DATE</u>
HORIZONTAL FAN COIL UNITS			
38F, 38FW, 38FE	Underfloor • Fan Booster • Unit Size 33 • Left Hand Layout	38F-33LH	8-20-08
38FW	Underfloor • Fan Booster • Hot Water Heat • Unit Size 33 • Left Hand Layout	38F-33LH	8-20-08
38FE	Underfloor • Fan Booster • Electric Heat • Unit Size 33 • Left Hand Layout	38F-33LH	8-20-08
38F, 38FW, 38FE	Underfloor • Fan Booster • Unit Size 33 • Right Hand Layout	38F-33RH	8-20-08
38FW	Underfloor • Fan Booster • Hot Water Heat • Unit Size 33 • Right Hand Layout	38F-33RH	8-20-08
38FE	Underfloor • Fan Booster • Electric Heat • Unit Size 33 • Right Hand Layout	38F-33RH	8-20-08
38FE	Underfloor • Fan Booster • Cooling and Heating Dampers • Unit Size 3H • High Capacity • Left Hand Layout	38FE-3HDLH	8-20-08
38FE	Underfloor • Fan Booster • Cooling and Heating Dampers • Unit Size 33H • High Capacity • Left Hand Layout	38FE-33HDLH	8-20-08
38FE	Underfloor • Fan Booster • Cooling and Heating Dampers • Unit Size 3H • High Capacity • Right Hand Layout	38FE-3HDRH	8-20-08
38FE	Underfloor • Fan Booster • Cooling and Heating Dampers • Unit Size 6H • High Capacity • Right Hand Layout	38FE-6HDRH	8-20-08
38FE	Underfloor • Fan Booster • Cooling and Heating Dampers • Unit Size 33H • High Capacity • Right Hand Layout	38FE-33HDRH	8-20-08
38FZ, 38FZW	Underfloor • Chilled Water and/or Hot Water • Unit Size 1	38FZ-1	10-20-08
38FZ, 38FZW	Underfloor • Chilled Water and/or Hot Water • Unit Sizes 3 and 5	38FZ-2	10-20-08
38S, 38SW, 38SE	Underfloor • Unit Sizes 1, 3 and 5	38S-1	4-20-09
38S, 38SW, 38SE	Underfloor • Heat Accessories • Unit Sizes 1, 3 and 5	38S-1	4-20-09